



1 Assembly manual closeable box trike



Overview of the parts

- 1. Front panel
- 2. Right panel
- 3. Left panel
- 4. Bench
- 5. Lock
- 6. Bracket
- 7. Sliding Lock





Step 1: Remove the existing parts

Remove the existing seat and supports on the left and right side. Remove the bolts for the seat.

Step 2: Pre-assembly left panel

Mount the sliding lock (5) on the left panel (2) with the 4 small screws.




Step 3: Pre-assembly right panel

Mount the bench magnet on the right panel (3) with the existing screws.


Step 4: Mount the side panels

Mount the left and the right panel (2 & 3) in the box with the existing screws.

Step 5: Pre-assembly front panel





2 Assembly manual closeable box trike



Mount the lock (4) on the front panel (1).
Make sure that the hook is facing upwars in the locking position of the lock.

Step 6: Slide the front panel in

Slide the front panel in the box and make sure the sliding lock fits in the front panel.





Step 7: Drill holes in the bench

Drill two holes with a diameter of 6 mm in the right side of the existing bench.

Step 8: Pre-assembly of the bench

Mount the lock bracket (6) on the existing bench with the two bolts and nuts.



Step 9: Mount the bench

Mount the bench in the box with the original screws.